

Drum Funnels & Equipment

Responsive



Safety Drum Funnels

Prevent spills when transferring flammable solvents, thinners, oils or paint wastes—self-closing lid in case of fire

- Wide-mouth, galvanized steel with durable powder-coat finish
- Models 08207 and 08205 include a built-in brass flame arrester that absorbs and dissipates heat, preventing any external ignition source from reaching the drum’s content. Model 08205 with a longer flame arrester provides greater liquid flow.
- For collection of viscous flammables or non-flammable liquids, use model 08208 fitted with a long open-ended brass tube to direct liquid flow
- Model 08203 prevents spillage from tip-over accidents and offers the same protection as drum funnel 08207 above, but includes an integral self-closing ball valve to prevent content spillage. System includes a brass vent to provide pressure and vacuum relief.
- FM-approved. EPA and OSHA compliant



Proper bonding and grounding techniques prevent static discharge and the potential for fire.



Pushing down handle opens ball valve to release liquid into drum.



Description	Funnel Dia x H	NPT/NPS	Approv/Lstg Regulation	Red Funnel Model	CA Prop 65	Yellow Funnel Model	CA Prop 65
Safety drum funnel with self-closing cover and 6 in (152 mm) flame arrester	10.75 x 10 in 273 x 254 mm	2 in (DN50)	FM, TÜV	08207	⚠	08227	⚠
Safety drum funnel with self-closing cover and 32 in (813 mm) flame arrester				08205	⚠	08206	⚠
Safety drum funnel with self-closing cover and 33 in (838 mm) brass tube				08208	⚠	—	
Safety drum funnel 08207 with tip-over protection system	—	2 in (DN50) and 0.75 in (DN20) vent	FM	08203	⚠	—	
Tip-over protection kit only for use with 08207 or 08205			FM	08214	⚠	—	

⚠ WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.